Introduction

The FNIRSI-5012H is a versatile, highly practical, cost-effective oscilloscope with FNIRSI's real-time sampling rate of up to 500MS/s and 100MHz analog bandwidth. With full trigger function (single, normal, automatic), it can meet the needs of both personal and small signals and non-periodic digital signals. Built-in high-voltage protection module, self-adjust up to 400V continuous voltage and 800V peak voltage. Don't worry about the oscilloscope burnout caused by the high voltage. Wide trigger sensitivity range: 1 div to 10 position. Large time base scan mode that monitors slow level changes. Equipped with a large 7-inch IPS screen, allows for the measured waveform can be displayed without complicated adjustments. Equipped with a high-capacity 5000mAh with 2.4-inch 320*240 resolution. Extremely convenient and fast waveform storage function, built-in 64M storage space, can store up to 2000 waveforms pictures. The storage process is simple and fast, save the current waveform anytime and anywhere, just one touch, no cumbersome tips and choices, quietly it is very convenient to see the current waveforms. Powerful waveform file manager, support for thumbnail preview, viewing, viewing, deleting page turning and more. Built-in 3000mah high-quality lithium battery can be used continuously for 16 hours when fully charged. The body is equipped with high-quality silicone protective cover, non-toxic and tasteless, anti-corrosion, anti-fouling, anti-dust, anti-drop and shockproof, comprehensive protection of the fuselage, soft touch, feel very comfortable.

Reminder

Reminder: the bandwidth of the 1X probe file is 5MHz, and the bandwidth of the 10X probe file is 100MHz. When the measurement is higher than 5MHz frequency, the switch on the probe handle needs to be moved to the 10X position, and the oscilloscope should also be set to the 10X position. Otherwise the signal will be greatly attenuated, as is the case with all oscilloscopes. Because the probe line of the oscilloscope itself has a capacitance up to 100~200pF, it is a large capacitance for the high frequency signal The signal has been greatly attenuated by the capacitance of the probe line, the oscilloscope. The equivalent bandwidth is 5MHz. Therefore, in order to match the probe line with hundreds of pF, the signal of the probe line is first attenuated by 10 times the switch is in 10X. A few hundred pF capacitors are used for impedance matching. The bandwidth at this time is 100MHz. Note that only probes with a bandwidth of 100MHz or more can be used.

Specifications

Model	FNIRSI-5012H	Digital trigger sensitivity	1.0 div - 10.0 div
Channels	1	Cursor	Position XY Trigger Y
LCD size	2.4 Inch	Scan mode	Support
Resolution	320*240	Storage depth	2000
Bandwidth	100MHz	Waveform Storage	Support
Sampling rate	500MS/s	Power	Up to 2000 wave
Bandwidth Rate	100MHz	Waveform Recall	Support
Vertical resolution	8 bits	Battery	3000mAh Lithium
Max time base	125ms	Handle	1 × Handle
Storage depth	128KB	Parameter	12 kinds in total
Vertical sensitivity	1mV/div - 10V/div	Battery	3000mAh Lithium
Time base	2ns/div - 125ms/div	Handle	1 × Handle
Time base scan	50ms - 125ms	Weight	1 × Handle
Trigger mode	Single/Normal/Auto	Dimensions	1 × Handle
Trigger source	CH1	Accessories	1 × Handle
Trigger sensitivity	AC/DC	Accessories	Leads, probe, USB data line, instructions

1X/10X model indicator lamp, this mode must be consistent with the 1X/10X position of the probe switch. When the probe is 1X, the 1X indicator light should also be set to 1X, 1X measures 0~80V, and the maximum input voltage of the oscilloscope is 400V.

Measured signal waveform

Measured waveform, the red line indicates the position indicates that the current position is 0V

Trigger position indicator icon

The voltage parameter of the measured waveform can be switched between 1X and 10X gear. The gear of the measured waveform, the measured value RMS, average value AVG and effective value RMS according to 1X.

Trigger level, the trigger level can be adjusted, the trigger level can be adjusted between 0 and 255. It can be adjusted to 10 grids, 1 is 0.4 grid, and the trigger level can be adjusted in the positive and negative duty cycle Dc.

Trigger voltage indicator icon

Waveform horizontal position

Sampling battery icon, given indicates remaining battery capacity, and in arrow indicates that the battery is currently charging

Trigger edge indicator icon

Trigger mode indicator icon. Single means single trigger. Normal means normal trigger, and Auto means automatic trigger.

Input coupling mode indicator icon. AC means AC coupling. DC means DC coupling.

Horizontal time base, indicating the length of time represented by a large square in the horizontal direction.

Port the power indicator icon, Blue means running, STOP means pause

Vertical sensitivity, which represents the voltage represented by a large grid in the vertical direction.

Direction keyboard

Click the "MODE" button to switch the keyboard operation mode, direction left and right keyboards, that is, the zoom mode and the move mode. Function icons are also displayed in the lower left corner of the screen.

The zoom mode of the waveform, that is, the vertical sensitivity and time base are adjusted. In this mode, the up and down keys are used to adjust the vertical sensitivity of the waveform, and the left and right keys are used to adjust the time base (the horizontal enlargement and decrease of the waveform).

The movement mode of the waveform, the waveform can be moved up, down, left and right keys adjust the trigger level, in the unidirectional trigger mode, the waveform can be moved left and right, the waveform can be moved only because the trigger point clock starts from the left starting point.

Instructions

Amplify the waveform: Use the 1X/10X button to set the direction keyboard to zoom mode, press the up button to vertically enlarge the waveform, and press the down button to vertically reduce the waveform.

Reduce the waveform: Use the 1X/10X button to set the direction keyboard to zoom mode, press the left button to vertically reduce the waveform, and press the left button to zoom out the waveform horizontally.

Move the waveform: Use the 1X/10X button to set the direction keyboard to move mode, press the up button to move the waveform up, press the down button to move the waveform down.

Adjust the trigger voltage: directly press the 2 up and down direction keys in the lower left corner of the oscilloscope to adjust the input signal when the trigger condition is satisfied. When the trigger mode is single or normal, the trigger level can be adjusted from 0 to 255. In the automatic trigger mode, the trigger level can be adjusted from 10% to 90% of the screen and the trigger level can only be adjusted from 10% to 90% of the screen.

Set the input coupling mode: directly press the (AC/DC) button on the direction keyboard to switch the input coupling mode.

Set the probe input magnification: First, you need to toggle the 1X/10X switch on the probe handle to the corresponding position, and then press the (1X/10X) button on the direction keyboard to set the input probe input magnification. For example, if the probe is moved to the 10X position, then the oscilloscope should also be set to the 10X position, and the input signal will be amplified by 10 times.

Pause: Press the (RUN/STOP) button on the keyboard to pause/run the waveform display.

Set the single trigger: directly press the (TRIG) button on the keyboard to set the single trigger. When the trigger condition is satisfied, the oscilloscope measures switching to the single trigger mode. First adjust the trigger line position, then press the (TRIG) button to enter the single trigger state, and then acquire the signal that meets the triggerconditions. It will automatically stop sampling after the single trigger is completed. If the trigger condition is not met, the oscilloscope will not trigger and will be in the unexpected state automatically triggering. Afterwards it can collect the signal of demand well.

Set the normal trigger: directly press the (TRIG) button on the keyboard, so that the brown area on the upper right of the screen displays "Normal". When the trigger condition is met, the oscilloscope will trigger and collect the signal. In normal trigger mode it is optimal the input signal when the trigger condition is met, and the oscilloscope will not trigger and collect the signal if it does not meet the trigger conditions. Note that this adjustment needs to turn off "Scan" or "Slow" mode, and the time base ranges from 100ns to 25ns.

Set the trigger edge: directly press the (EDGE) on the keyboard to switch the rising and falling edges of the trigger.

Set the automatic trigger: directly press the (TRIG) button on the keyboard, so that the brown area on the upper right of the screen displays "Auto".

It may be that after the final test is completed, the tester forgets to shut the probe switch back to the 10X position, and the oscilloscope is set to the 10X gear, there is no power. Please change it with USB for 5 minutes and then turn it on. At this time, the probe switch is set to the 1X position, and the oscilloscope is set to the 1X position, but the waveform will be synchronized after switching the probe switch.

Show/hide more measurement parameters: press the (MENU) button to show/hide more measurement parameters. There are 12 kinds of parameters in total, and the measurement parameters can be selected. The last measurement parameter that is already being displayed, and up to 12 can be displayed simultaneously.

Show/hide Background Grid: Press the (MENU) button to enter thesecond-level menu, press the (MENU) button in the second-level menu to show or hide the black dot indicators that current setting. Then exit the menu page and you will see the change in the background grid on the screen.

The setting is automatically 50% triggered each time: press the (MENU) button to enter the second-level menu, press the (MENU) button in the second-level menu, indicated by the front black dot indicates the current setting. After setting, it will automatically trigger the signal to be displayed in the middle of the screen when the signal is triggered, so that the signal can be quickly and conveniently observed.

Set the Hertzgive level (phantomgear): press the (MENU) button to enter the menu page, select "Multi-Buffer" to set, and the position indicated by the red line is the current position. When the signal is triggered, the waveform will be displayed in the middle of the screen. When the signal is not triggered, the waveform refreshes, the larger the number of Hertzgive levels, the more stable the waveform, but the refresh speed is slow. It is necessary to observe that a certain part of the signal is displayed at a fixed position, and the Hertzgive level can be set to a larger value, and the waveform will be more stable.

Store the waveform: Press the (SAVE) button on the keyboard directly. At this time, the waveform of the current screen is saved. The save time is very fast, and the waveform can be saved in 0.1 second. Includes 12 kinds of measurement data, vertical sensitivity and time base.

View the saved waveform: press the (MENU) button to enter the menu page, select "Waveform Storage", and the thumbnails of the saved waveform will be displayed as a thumbnail. It is very convenient to quickly preview the saved waveform. Press the (OK) button to enter the waveform in full screen, and then (OK) can display vertical sensitivity and time base information.

Delete the saved waveform: Under the Wave File Manager interface, move the cursor to the file to be deleted, and then press and hold the (OK) button (RUN/STOP) button to delete the currently selected waveform, or press the (STOP) button to cancel the deletion. Deleted files can be restored by the oscilloscope's data recovery function.

Waveform manager page: In the waveform file manager interface, press (U) to page forward, press (D) to page backward. Horizontal

Common problem

1. Why can't I open the oscilloscope?

2. Why is the signal displayed on the screen too small?

3. Why is the signal displayed on the screen too large?

4. Why is the signal displayed on the screen too slow?

5. Why is the signal displayed on the screen too fast?

6. Why is the signal displayed on the screen too dim?

7. Why is the signal displayed on the screen too bright?

8. Why is the signal displayed on the screen too dim?

9. Why is the signal displayed on the screen too bright?

10. Why is the signal displayed on the screen too dim?

11. Why is the signal displayed on the screen too bright?